

Channel Configuration defaults

For the actual description of the parameters see the Technical manual Chapter 4, subsection: assigning channels. Some parameters have recommended defaults (see below), although they will more than likely not be the most efficient settings this is a list of defaults that will get you feeding product successfully. These settings should be tuned by a specialist after initial feeds have been completed to help maximize overall system performance.

Minimum Material addition	0
Dump Trip Point	3 % of the Scale Capacity
Flow Rate Thresholds	
• Zero	5 scale divisions (NOTE: if you have a noisy process or agitator this value could be increased to 10 or 15)
• Unstable Device	2 times larger than the above mentioned Zero Threshold
• Minimum PAC	1.5 times the Zero Threshold
Skip Drain Timer After Zero Flow	Leave this box unchecked
Process Times	
Feed Override Time	0
Minimum Slow Step Time	30
Stable Measuring Device Wait Time	3
Overlap Feed Alone Time	8 (Not default setting required in Q.i Lite)
Overlap Feed Alone Tolerance	8 (Not default setting required in Q.i Lite)